



Comment:

s/n 0001 - 09648

Part #	Raw Mat #	Description	WD Cost	List Cost
6202		Clamps (1 Pair)	\$0.00	\$0.00
6204		Jaw Kit (Repairs 1 Clamp)	\$0.00	\$0.00
600121		Meter Cover	\$0.00	\$0.00
602101		Positive Clamp Assy	\$0.00	\$0.00
602102		Negative Clamp Assy	\$0.00	\$0.00
603147		Pointer Knob	\$0.00	\$0.00
604579		Stop/Go Lite	\$0.00	\$0.00
605183		Front Leg	\$0.00	\$0.00
605184		Wheel Kit	\$0.00	\$0.00
605185		Axle w/Nuts	\$0.00	\$0.00
605186		Base	\$0.00	\$0.00
605193		Solenoid	\$0.00	\$0.00
605197		AC Circuit Breaker	\$0.00	\$0.00
605203		6 Pos. Switch w/Knob	\$0.00	\$0.00
610895		Knob w/Screw	\$0.00	\$0.00
605204		Amps Charge Meter	\$0.00	\$0.00
605205		AC Cord (14/3)	\$0.00	\$0.00
605207		DC Cable Set	\$0.00	\$0.00
605209		Side Panel (1)	\$0.00	\$0.00
605210		Front or Rear Panel (1)	\$0.00	\$0.00
605211		Lid	\$0.00	\$0.00
605213		Handle	\$0.00	\$0.00
605675		Switch w/Knob	\$0.00	\$0.00
610123		Circuit Breaker Kit (Triple)	\$0.00	\$0.00
610125		Rectifier	\$0.00	\$0.00
610138		Top Panel	\$0.00	\$0.00
610189		Fan Blade	\$0.00	\$0.00
610190		Fan Motor	\$0.00	\$0.00
610389		Timer w/Knob	\$0.00	\$0.00