



Comment: When reassembling the unit make sure to separate wires. Black & white to switch on one side, black & white to load on the other side. The two green wires should be directly up the center of the cabinet. This reduces the magnetic effect to the meter. For best results, make sure the Neg cable is installed on the back side of the divider in the handle.

Part #	Raw Mat #	Description	WD Cost	List Cost
610263		Load Switch	\$0.00	\$0.00
610264		Positive cable and clamp	\$0.00	\$0.00
610265		Negative cable and clamp	\$0.00	\$0.00
610270		Circuit Board	\$0.00	\$0.00
610271		Test Lead	\$0.00	\$0.00
610294		Indicator Lamp	\$0.00	\$0.00
610375		Load Meter	\$0.00	\$0.00
610411		Insulator Board	\$0.00	\$0.00
610412		Load Element	\$0.00	\$0.00
610413		Female Plug	\$0.00	\$0.00

