



Comment:

Blank comment box.

Part #	Raw Mat #	Description	WD Cost	List Cost
604579		Stop/Go Lite	\$0.00	\$0.00
605204		Amps Charge Meter (old p/n was 610146 & 610268)	\$0.00	\$0.00
605206		AC Cord	\$0.00	\$0.00
605671		Leg	\$0.00	\$0.00
605672		Wheels w/Nuts	\$0.00	\$0.00
605675		Switch w/Knob	\$0.00	\$0.00
610052		Axle w/Nuts	\$0.00	\$0.00
610054		Base	\$0.00	\$0.00
610069		DC Circuit Breaker	\$0.00	\$0.00
610078		Back Panel	\$0.00	\$0.00
610122		Rectifier	\$0.00	\$0.00
610149		Top Panel	\$0.00	\$0.00
610151		Left Side Panel	\$0.00	\$0.00
610152		Right Side Panel	\$0.00	\$0.00
610153		Handle	\$0.00	\$0.00
610154		Front Panel	\$0.00	\$0.00
610189		Fan Blade	\$0.00	\$0.00
610190		Fan Motor	\$0.00	\$0.00
610201		Transformer	\$0.00	\$0.00
610242		Thermal Fuse	\$0.00	\$0.00
610258		DC Cable set (old p/n was 605677)	\$0.00	\$0.00
610389		Use when 610390 is depleted	\$0.00	\$0.00
610390		Timer w/Knob (old p/n was 610133)	\$0.00	\$0.00