



Comment: When reassembling the unit make sure to separate wires. Black & white to switch on one side, black & white to load on the other side. The two green wires should be directly up the center of the cabinet. This reduces the magnetic effect to the meter. For best results, make sure the Neg cable is installed on the back side of the divider in the handle.

| Part # | Raw Mat # | Description                      | WD Cost | List Cost |
|--------|-----------|----------------------------------|---------|-----------|
| 610264 |           | Positive Cable & Clamp           | \$0.00  | \$0.00    |
| 610265 |           | Negative Cable & Clamp           | \$0.00  | \$0.00    |
| 610412 |           | Load Element                     | \$0.00  | \$0.00    |
| 610411 |           | Insulator Board                  | \$0.00  | \$0.00    |
| 610263 |           | Load Switch                      | \$0.00  | \$0.00    |
| 610375 |           | Load Meter                       | \$0.00  | \$0.00    |
| 610408 |           | Housing w/Handle                 | \$0.00  | \$0.00    |
| 610410 |           | Housing cover                    | \$0.00  | \$0.00    |
| 6200   |           | Side Terminal Adapter (pkg of 2) | \$0.00  | \$0.00    |
|        | 027-0605  | Manual                           | \$0.00  | \$0.00    |



