


Wiring Diagram



Model BCH7111A Parts List

605671	FRONT LEG	610069	DC CIRCUIT BREAKER (1)
605672	WHEELS W/NUTS	610287	AXLE W/NUTS
605213	HANDLE	610188	TRANSFORMER
604579	STOP/GO LITE	610418	RECTIFIER
610189	FAN BLADE	6202	CLAMPS (1 PAIR, INCLUDES JAWS)
610190	FAN MOTOR	6204	JAW KIT (REPAIRS ONE CLAMP)
605206	AC CORD	610389	TIMER W/KNOB
605675	SWITCH W/KNOB	610324	AMPS CHARGE METER
605207	DC CABLE SET		