


MC425 WIRING DIAGRAM



MODEL MC425 REPAIR PARTS LIST

Item	Description	Part no.
1.	Switch	611000
2.	Axle w/nuts	610052
3.	Wheels w/nuts	605672
4.	Transformer	611096
5.	Panel, Front	611109
6.	Panel, Back	610977
7.	Rectifier	611097
8.	Leg	610825
9.	DC Circuit Breaker (1)	611028
10.	Ammeter	610695
11.	AC Cord	610696
12.	DC Cable Set	610824
13.	Handle	605213
14.	Base	610054
15.	Panel, Right Side	611104
16.	Panel, Top	611105
17.	Timer, w/knob	610895
	Panel, Left Side (not shown)	611106

